



**Repair
Kit
385**

<u>Part#</u>	<u>Description</u>	<u>Qty.</u>
0084	SPREAD FINGER	x 3
0088	O-RING (Piston)	x 1
0089	O-RING (Brass Sleeve)	x 1
0092	PISTON CUP (Large)	x 1
0095	SPRING (Trigger)	x 1
0096	PIN (Trigger)	x 1
0098	TRIGGER (w/ O-Rings)	x 1
0103	SPRING-RING (Head)	x 1
0126	INSERTING FINGER	x 3
0127	METERING LEVER	x 3
0129	PISTON	x 1
0130	FEED TUBE	x 1
0131	TAPERED SLEEVE	x 1
0135	STEEL RING	x 1
0134	COMPRESSION SPRING	x 1
0136	O-RING (Feed Tube)	x 1
0383	PISTON CUP (Small)	x 1