



SPARE PARTS LIST

5 Ton Long Chassis Service Jack

Model # 22050

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	G25-6-1201-107	Base	1	46	667-5-0180-009	Retaining Ring "C"	2
2*	503-9-0050-106	Spring Cap	1	47	421-6-9001-305	Pin	1
3	644-1-0060-05311	Screw	1	48	410-4-4010-203	Bearing	2
4*	511-7-1164-108	O-ring	2	49	611-3-0130-101	Washer	2
5*	511-7-0738-106	O-ring	1	50	661-2-0120-010	Nut	2
6*	577-7-0802-109	Back-up Ring	1	51	521-2-0220-004	Extention Spring	1
7	532-8-0050-024	Filter	1	52	677-5-0240-018	Returning Ring "E"	2
8	421-6-1203-206	Reservoir	1	53	601-8-0006-001	Grease Fitting Nipple	3
9*	505-9-0092-207	Filler Plug	1	54	500-1-1100-019	Front Wheel	2
10	421-6-1807-208	Cylinder	1	55	421-6-4001-209	Saddle	1
11*	521-7-0670-014	U-cup	1	56	G25-3-6000-104	Chassis	1
12*	577-7-0670-014	Back-up Ring	1	57	G25-6-4120-102	Cover	1
13	421-6-1109-103	Bearing Cover	1	58	614-1-0060-02211	Screw	4
14	421-3-1200-303	Piston Rod Assy.	1	59	421-6-2202-209	Knob	1
15	421-6-1204-309	Top Nut	1	60	601-4-0040-034	Spring Pin	1
16*	511-7-0530-111	O-ring	1	61	421-3-9001-105	Release Valve Rod	1
17*	551-7-0060-066	Oil Seal	1	62	605-3-0050-103	Spring Washer	2
18	614-1-0050-04711	Screw	1	63	609-1-0050-10911	Screw	1
19	425-6-1303-107	Release Valve	1	64	G10-3-2300-204	Handle	1
20	G25-3-1300-202	Universal Joint Assy.	1	65	A07-6-2204-102	Washer	1
21	524-2-0240-111	Compression Spring	1	66	524-2-0138-019	Compression Spring	1
22	421-4-1500-109	Hyd. Cartridge Assy.	1	67	511-3-0105-011	Washer	1
23*	581-7-0195-009	Packing	2	68	602-4-0025-017	Cotter Pin	1
24*	531-3-0270-021	Washer	1	69	421-6-0100-100	Grip	1
25	421-6-1401-604	Pump Cylinder	1	70	421-6-2107-306	Pin	1
26*	521-7-0160-011	U-cup	1	71	602-4-0025-026	Cotter Pin	1
27*	573-7-0162-019	Back-up Ring	1	72	421-6-2106-203	Pin	1
28*	511-7-0120-406	O-ring	1	73	531-3-0207-107	Washer	1
29*	573-7-0160-024	Back-up Ring	1	74	G10-6-1104-106	Locking Pin	1
30	421-6-1402-404	Pump Piston	1	75	421-6-2102-104	Handle Fork Collor	2
31	421-6-9005-202	Pin	2	76	506-9-0264-106	Handle Grip	1
32	513-5-0018-012	Returning Pin	2	77	511-3-0192-012	Washer	2
33	421-3-9010-409	Piston Link	1	78	421-6-5020-107	Rubber Pad	2
34	521-2-0155-018	Returning Spring	1	79	421-3-5100-208	Caster	2
35	486-6-1302-100	Washer	1	80	421-4-5100-103	Caster Assy.	2
36	653-1-0060-072	Bolt	1	81	G25-1-1000-116	Power Unit	1
37	A20-4-1500-106	Hyd. Cartridge Assy.	1	—	G25-3-9901-107	Repair Kit	-
38	653-1-0064-061	Bolt	1				
39	421-3-9004-101	Foot Pedal	1				
40	421-6-2404-100	Bushing	1				
41	421-6-2403-108	Bushing	1				
42	421-4-1300-101	Handle Fork (incl. #75)	1				
43	651-2-0100-007	Nut	1				
44	605-3-0100-203	Spring Washer	1				
45	653-1-0100-078	Bolt	1				

* - Repair Kit includes item# 2, 4, 5, 6, 9, 11, 12, 16, 17, 23, 24, 26, 27, 28 & 29



SPARE PARTS LIST

5 Ton Long Chassis Service Jack

Model # 22050


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	N/A	Base	1	46	667-5-0180-009	Retaining Ring "C"	2
2	*	Spring Cap	1	47	421-6-9001-305	Pin	1
3	644-1-0060-05311	Screw	1	48	410-4-4010-203	Bearing	2
4	*	O-ring	2	49	611-3-0130-101	Washer	2
5	*	O-ring	1	50	661-2-0120-010	Nut	2
6	*	Back-up Ring	1	51	521-2-0220-004	Extention Spring	1
7	532-8-0050-024	Filter	1	52	677-5-0240-018	Returning Ring "E"	2
8	421-6-1203-206	Reservoir	1	53	601-8-0006-001	Grease Fitting Nipple	3
9	*	Filler Plug	1	54	500-1-1100-019	Front Wheel	2
10	N/A	Cylinder	1	55	421-6-4001-209	Saddle	1
11	*	U-cup	1	56	N/A	Chassis	1
12	*	Back-up Ring	1	57	G25-6-4120-102	Cover	1
13	421-6-1109-103	Bearing Cover	1	58	614-1-0060-02211	Screw	4
14	N/A	Piston Rod Assy.	1	59	421-6-2202-209	Knob	1
15	N/A	Top Nut	1	60	601-4-0040-034	Spring Pin	1
16	*	O-ring	1	61	421-3-9001-105	Release Valve Rod	1
17	*	Oil Seal	1	62	605-3-0050-103	Spring Washer	2
18	614-1-0050-04711	Screw	1	63	609-1-0050-10911	Screw	1
19	425-6-1303-107	Release Valve	1	64	G10-3-2300-204	Handle	1
20	G25-3-1300-202	Universal Joint Assy.	1	65	A07-6-2204-102	Washer	1
21	524-2-0240-111	Compression Spring	1	66	524-2-0138-019	Compression Spring	1
22	421-4-1500-109	Hyd. Cartridge Assy.	1	67	511-3-0105-011	Washer	1
23	*	Packing	2	68	602-4-0025-017	Cotter Pin	1
24	*	Washer	1	69	421-6-0100-100	Grip	1
25	421-6-1401-604	Pump Cylinder	1	70	421-6-2107-306	Pin	1
26	*	U-cup	1	71	602-4-0025-026	Cotter Pin	1
27	*	Back-up Ring	1	72	421-6-2106-203	Pin	1
28	*	O-ring	1	73	531-3-0207-107	Washer	1
29	*	Back-up Ring	1	74	G10-6-1104-106	Locking Pin	1
30	421-6-1402-404	Pump Piston	1	75	N/A	Handle Fork Collor	2
31	421-6-9005-202	Pin	2	76	506-9-0264-106	Handle Grip	1
32	513-5-0018-012	Returning Pin	2	77	511-3-0192-012	Washer	2
33	421-3-9010-409	Piston Link	1	78	421-6-5020-107	Rubber Pad	2
34	521-2-0155-018	Returning Spring	1	79	N/A	Caster	2
35	486-6-1302-100	Washer	1	80	421-4-5100-103	Caster Assy.	2
36	653-1-0060-072	Bolt	1	81	G25-1-1000-116	Power Unit	1
37	A20-4-1500-106	Hyd. Cartridge Assy.	1	-	G25-3-9901-107	Repair Kit	-
38	653-1-0064-061	Bolt	1	* - Repair Kit includes item# 2, 4, 5, 6, 9, 11, 12, 16, 17, 23, 24, 26, 27, 28 & 29			
39	421-3-9004-101	Foot Pedal	1				
40	N/A	Bushing	1	N/A - Parts not available			
41	N/A	Bushing	1				
42	421-4-1300-101	Handle Fork (incl. #75)	1				
43	651-2-0100-007	Nut	1				
44	605-3-0100-203	Spring Washer	1				
45	653-1-0100-078	Bolt	1				



PARTS ILLUSTRATION

5 Ton Long Chassis Service Jack

Model # 22050



Exploded Drawing
2nd Edition © Jul 2005

22050-S0