




World Leader in Lift Productivity

P
A
R
T
S

B
R
E
A
K
D
O
W
N

VLX6, VLXS6, VLXS6-1,-2,-3,-4 VLX6-EU, VLXS6-EU



IMPORTANT: When ordering parts or requesting service always give exact model and power unit serial number. Model number is shown on nameplate attached to power unit column. Power unit serial number is located on side of power unit.

OWNERS RECORD

Complete information
at right and keep in
a safe place.

Date Installed _____

Installed in Bay # _____

Power Unit Serial # _____

Power Unit Model # _____


Lift Serial # _____

Lift Model # _____

NOTE: For replacement parts -See your nearest Rotary Parts Distributor.

PB2-5-5-1

Rev. G 08/07/2003



VLX6, VLXS6, VLXS6-4 REPLACEMENT PARTS

ITEM NO.	DESCRIPTION	PART NO.	ITEM NO.	DESCRIPTION	PART NO.
1	Leg Bolt Kit	FJ2260	20	5/8"-11NC HHCS x 8 1/2" Lg. Gd. 8	40359
2	Front Leg Assembly	FJ2244	21	Nut	FJ2298-8
3	3/8" X 1" Flange Head Cap Screw	40144	22	Locking Leg Assembly	FJ2458
4	Pad	FJ2433	23	Release Handle Assembly	FJ2390
5	Cylinder Bracket	FJ2293-1	24	Foot Pump Power Unit (VLX6, VLX6-EU) Air	P831
6	Superstructure Assembly	FJ2459	25	1/8" x 1 1/4" Cotter Pin	41201
7	Pad Weldment	FJ2386-1	26	Machinery Bushing Washer	FJ2252-4
8	Rubber Adapter Block - 1 1/2"	FJ2427	27	Hydraulic Cylinder	FJ2248
9	Rubber Adapter Block - 3" (optional)	FJ2428	28	Hose	FJ85
10	1/4"-20 Flange Whiz-Loc	40641	29	Optional Cylinder Cover	FJ2280
	1/4"-20 Flange Socket BHCSH	40077	30	3/8" Concrete Anchor	FC5388-98
11	Ramp Weldment	FJ2387		Power Unit Stand	FJ864
12	Plastic Ramp Slide	FC5142-3	31	7" Power Unit Stand (VLXS6-4)	FJ2453
13	Hinge Pin	FJ2388		Dual Power Unit Stand (VLXS6-2)	FJ570
14	Retainer	FJ2434		Power Unit (VLXS6) 115V 10 60 HZ.	P833
15	3/4" Concrete Anchor	FJ2377	32	Power Unit (VLXS6-EU) 1380V/30 50 HZ.	P1102
	HSL M12/25 Concrete Anchor (EU versions)	FJ2455		Power Unit (VLXS6-1EU) 220V 10 50 HZ.	P1117
16	Rear Leg Assembly	FJ2245	33	VLX Retainer Base	FJ2392
17	Front Base	FJ2370	34	Retainer Bolt	40439
18	Wheel Spotting Dish	FF729-1	35	Toe Guard (Euro version only)	FJ2450
19	Drive Anchor	FJ7659-2	36	Elbow Adapter	P1028-4
			37	P/U Wall Mount Bracket	T120020
			38	Power Unit Stand Cap	FJ2467

NOTES:

Installer: Please return this booklet to literature package, and give to lift owner/operator.

Thank You

Trained Operators and Regular Maintenance Ensures Satisfactory Performance of Your Rotary Lift.

Contact Your Nearest Authorized Rotary Parts Distributor for Genuine Rotary Replacement Parts. See Literature Package for Parts Breakdown.

World Headquarters:
Rotary Lift
A  **DOVER** COMPANY
2700 Lanier Drive
Madison, Indiana USA
Phone: 1.800.445.5438
Phone: 1.812.273.1622
Fax: 1.800.578.5438
Fax: 1.812.273.6502
userlink@rotarylif.com
www.rotarylif.com

Italy:
(Regional Sales Office)
Rotary Lift Europe S.r.l.
Cadriano (BO)
Phone: +39.051.763384
Fax: +39.051.763395
info@rotaryeurope.com

Germany:
(European Sales Headquarters)
Rotary Lift Germany GmbH
Bensheim
Phone: +49.6251.582.6420
Fax: +49.6251.582.6422
sales@rotarylif.de

United Kingdom:
(Regional Sales Office)
Rotary Lift (UK) LTD.
Halstead, Essex
Phone: +44.178.747.7711
Fax: +44.178.747.7720
sales@rotarylif.idps.co.uk

Canada:
(Regional Sales Office)
Rotary Lift Canada
Mississauga, Ontario
Phone: 905.812.9920
Fax: 905.812.9719
canada@rotarylif.com

Austral-Asia:
(Regional Sales Office)
Rotary Lift Austral/Asia
Petaling Jaya, Malaysia
Phone: +60.3.7660.0285
Fax: +60.3.7660.0289
rlim@rotarylif.com

